

TOOLS NEEDED:

- Phillips screwdriver
- Flat head screwdriver
- 10mm Socket

INSTALLATION DIFFICULTY:



TIME OF INSTALLATION:

Approximately
15 Minutes

We highly recommend that you check your filter every 3000 miles or sooner in harsh environments. For complete cleaning instructions please see the enclosed Green booklet.

For complete filter warranty information please refer to the enclosed Green booklet.

If you live or travel in a harsh environment we recommend that you purchase a Quadzilla Pre-Filter.

Quadzilla Pre-Filters are designed for the purpose of preventing large particles such as rubbery, dirt and sand from clogging the filter pleats. Premature clogging of an air filter will result in loss of horsepower and an increase in service intervals. Quadzilla pre-filters are uniquely designed to protect your engine and the performance air filter investment without sacrificing airflow or horsepower.

WWW.QUADZILLAPOWER.COM

THIS IS A HIGH PERFORMANCE PRODUCT. USE AT YOUR OWN RISK

Do not use this product until you have carefully read the following agreement.

This sets forth the terms and conditions for the use of this product. The installation of this product indicates the BUYER has read and understands this agreement and accepts the terms and conditions.

DISCLAIMER OF LIABILITY

Quadzilla Performance Technologies, Inc. (hereafter SELLER) shall in no way be liable for the products proper use and service. THE BUYER HERBY WAVES ALL LIABILITY.

The BUYER acknowledges that he/she is using the product on the SELLER'S skill or judgment to select or furnish goods suitable for a particular purpose and that there are no liabilities which extend beyond the description of the goods and the BUYER hereby waives all remedies or liabilities, expressed or implied, in any law or otherwise, (including consequential damages) without any obligations of the SELLER for negligence, merchantability and consequential damages) or whether caused in whole or in part by the SELLER'S negligence.

The SELLER disclaims any warranty and liability for personal injury or damages. The BUYER acknowledges that the SELLER disclaims any liability for personal injury or a material term for the use of the product. The BUYER agrees to indemnify the SELLER and to hold the SELLER harmless from all claims, damages, losses, expenses or expenses by reason of use or sales of the product. The BUYER shall be liable for any damages or expenses by reason of use or sales of the product.

The SELLER assumes no liability regarding the use of the product or misapplication of its products. It is the installer's responsibility to ensure proper installation and if in doubt, contact the manufacturer.

LIMITATION OF WARRANTY

Quadzilla Performance Technologies, Inc. (hereafter SELLER) warrants its product to description, quality, merchantability, fitness for use and performance. The SELLER provides a limited warranty as stated in the enclosed Green booklet.

The SELLER disclaims any liability for personal injury or damages. The BUYER acknowledges that the SELLER disclaims any liability for personal injury or a material term for the use of the product. The BUYER agrees to indemnify the SELLER and to hold the SELLER harmless from all claims, damages, losses, expenses or expenses by reason of use or sales of the product. The BUYER shall be liable for any damages or expenses by reason of use or sales of the product.

The SELLER disclaims any liability for personal injury or damages. The BUYER acknowledges that the SELLER disclaims any liability for personal injury or a material term for the use of the product. The BUYER agrees to indemnify the SELLER and to hold the SELLER harmless from all claims, damages, losses, expenses or expenses by reason of use or sales of the product. The BUYER shall be liable for any damages or expenses by reason of use or sales of the product.

Under no circumstances shall the SELLER be liable for any labor charged or travel time incurred in diagnosis for defects, removal, or reinstallation of this product, or any other contingent expenses.

Under no circumstances shall the SELLER be liable for any damages or expenses incurred by reason of the use of sale of any such equipment.

THE INSTALLATION OF THIS PRODUCT INDICATES THAT THE BUYER HAS READ AND UNDERSTANDS THIS AGREEMENT AND ACCEPTS ITS TERMS AND CONDITIONS.

QUADZILLA PERFORMANCE

MAIC



GM 6.6 Liter Instruction Manual



WWW.QUADZILLAPOWER.COM

Instructions



01-05 Duramax Intake

1 Removing Stock Air Filter

1A Remove the factory mass air sensor using a Phillips head screwdriver.

1B Loosen the band clamp holding the rubber intake tube to the air box using a flat head screwdriver or a 5/16 nut driver.

1C Remove the factor air box by gently lifting it straight out of the vehicle.



2 Installing the Quadzilla Monster Air Intake

2A Remove the filter from the Monster Air Intake. Be careful not to damage the filter pleats when handling the filter.




2B Remove the four bolts holding the intake tray onto your vehicle using a 10mm socket. The plate will stay in place and the new intake will sit on top of it.

2C Install the Quadzilla Monster Air Intake by aligning the holes in the intake with the holes where bolts were removed. Attach the intake to the truck by fastening the factory bolts into the 4 holes and tightening them.



2D Install the filter back on the intake.

2E Reinstall the factory mass air sensor into the Quadzilla Monster Air Intake using the two supplied Phillips head machine screws. Re-attach the rubber intake tube to the Quadzilla Monster Air Intake and tighten the band clamp.



Notes:

We recommend that you store any stock pieces that have been removed. If for any reason you decide to reinstall the stock intake you will need all of these pieces.

www.QuadZillaPower.com